


USER MANUAL



Up and down Forklift arm



The flexible excavator arm can swing up and down



Gear sounds when kids rotating



Hold something inside and close



Press the button swing up and down

Push and Go!



Gently push the car to make it slide. It can run smoothly on smooth surfaces, but may have difficulty running on carpeted floors

